

Woodside Security Systems Ltd

OPERATION OF YOUR INTRUDER ALARM SYSTEM TO SET DATE AND TIME

To set date and time, with the keypad displaying:

WOODSIDE SYSTEMS
TIME (00:00) c

Press the **D** button and enter your four (4) digit **Master Manager Code** or present the **Master Tag**. The following "Set date & Time" display will only come up if the correct code is entered or correct Master Tag is presented.

SET DATE AND TIME?

Press **Yes** button on the keypad and the screen will display:-

Year (00-99)

Enter Year (eg. 09 = 2009) and press YES again

The keypad and the screen will now display:-

Month (1-12)

Enter Month (eg. 06 = JUNE) and press YES again

The keypad and the screen will now display:-

Day (1-31)

Enter Day (eg. 09 = 9th) and press YES again

The keypad and the screen will now display:-

Hours (00-23)

Enter hours (eg. 13 = 1pm – 24 hour clock) and press YES again

The keypad and the screen will now display:-

Minutes (00-59)

Enter minutes (eg. 05) and press YES again

The keypad and the screen will now display:-

SET DATE AND TIME?

PRESS THE "A" BUTTON TO SAVE & RETURN TO MAIN DISPLAY MENU (ie. Woodside Systems)

Final screen will now display:-

WOODSIDE SYSTEMS
TIME 13:05 c

.....
.....
ALTERNATIVELY FROM:

SET DATE AND TIME?

- PRESS NO TO GET TO **OMIT INPUTS** MENU
- PRESS NO AGAIN TO GET TO **CHANGE CODES** MENU
- PRESS NO AGAIN FOR **REVIEW LOGS** MENU

.....OR PRESS THE "A" BUTTON TO RETURN TO MAIN WOODSIDE SYSTEMS DISPLAY SCREEN